DENTAL PHOTOGRAPHY SETTINGS

Setting Wheel	M - Manual	Setting Wheel	M - Manual
ISO	100	White Balance	Flash
Shutter Speed	1/200	Metering Mode	Centre- weighted
F Stop Intra Oral	Anything between 25-32	Colouring	sRGB
F Stop Artistic Smile	18	Picture Control Canon	Faithful
F Stop Face/ Portrait	11	Picture Control Nikon	Vivid
Image Format	RAW + JPG	Flash Setting	Manual 1/1

VendGrow.com

